



Qulu to NX Witness transfer Licenses

Part Code (Short Description)	Strats code	Long Description
L01-NXWI-QR qulu to NX Rec lic no HW	0646270	Qulu to NX witness single channel recording license transfer fee, used when hardware IS NOT CONVERTED to Veracity Coldstore
L05-NXWI-QR qulu to NX V/Wall lic no HW	0646280	Qulu to NX witness Video wall license transfer fee, used when hardware IS NOT CONVERTED to Veracity Coldstore
L08-NXWI-QR qulu to NX I/O lic no HW	0646290	Qulu to NX witness I/O module license transfer fee, used when hardware IS NOT CONVERTED to Veracity Coldstore
L06-NXWI-QR qulu to NX ENC lic no HW	0646300	Qulu to NX witness 4 Chn Encoder license transfer fee, used when hardware IS NOT CONVERTED to Veracity Coldstore
L01-NXWI-QC qulu to NX Rec lic with HW	0646310	Qulu to NX witness single channel recording license transfer fee, used when hardware IS CONVERTED to Veracity Coldstore
L05-NXWI-QC qulu to NX V/Wall lic with HW	0646320	Qulu to NX witness Video wall license transfer fee, used when hardware IS CONVERTED to Veracity Coldstore
L08-NXWI-QC qulu to NX I/O lic with HW	0646330	Qulu to NX witness I/O module license transfer fee, used when hardware IS CONVERTED to Veracity Coldstore
L06-NXWI-QC qulu to NX ENC lic with HW	0646340	Qulu to NX witness 4 Chn Encoder license transfer fee, used when hardware IS CONVERTED to Veracity Coldstore
L01-NXWI NX Witness single chn Rec Lic	0646350	NX Witness single channel recording Licence
L05-NXWI NX Witness Video Wall lic	0646360	NX Witness Video Wall Licence
L08-NXWI NX Witness I/O mod lic	0646370	NX Witness I/O Module Licence
L06-NXWI NX Witness 4 Chn Encoder lic	0646380	NX Witness Encoder Licence